



## OIL/LIQUID EXTRACTOR

Thank you for choosing this fine product from GRIOT'S GARAGE. Your OIL/LIQUID EXTRACTOR is simple to operate and suitable for extracting engine oil, gear oil, transmission fluid, brake fluid, water and other liquids. It's the cleanest way to extract fluids. Enjoy the best!

### USEFUL INSTRUCTIONS

When using this unit to remove engine oil, make sure the vehicle is level. Run a cold engine for approximately 5 minutes to warm the oil and allow any sludge or contaminants to mix. If the engine is hot, allow enough time for the engine to cool to a warmer condition. Extracting hot oil or liquids can melt or destroy this product and may be hazardous and/or cause burns.

1. Remove the oil dipstick from the engine.
2. Select and insert the appropriate diameter extracting tube into the dipstick hole until it reaches the bottom of the oil pan.
3. Connect the main suction tube into the extractor. The main suction tube will connect to the extracting tube at the rubber fitting. Raise the extractor's handle to its highest position and fully pump the handle up and down several times to start the flow of liquid. Once fluid begins to fill the tank there is no need to keep pumping. The unit will automatically extract the fluid. Note that when the liquid flows into the unit, it will raise the internal float. When the float reaches the top of the tank the shut off valve will automatically stop the flow, even if the unit is still under vacuum. Press the relief valve button on top of the unit for approximately five seconds to release the vacuum, then remove the main suction tube from the unit and pour the liquid out. Please dispose of fluids in an appropriate manner.

### WARNINGS AND CAUTIONS!

**Do not** use the unit to extract or store dangerous chemicals, poisons, acids, alkalis or solvents. Flammable products (e.g. petrol, gasoline, diesel, kerosene) may be extracted or siphoned with this unit, but they must **not** be stored in it. Always use in a well ventilated area. **Do not** store either the unit or suction tubes near or in areas of high temperatures, open flames, direct sunlight, rain or snow. **Do not** drop, throw or mishandle the OIL/LIQUID EXTRACTOR and **do not** dismantle, tamper with or adapt the unit for any other purpose than for what it was originally intended. Dispose of fluid in accordance with your local rules and regulations. **Keep all oils and solvents out of the reach of children.**

### DISCLAIMER

GRIOT'S GARAGE is not responsible for the misuse of the OIL/LIQUID EXTRACTOR or for any injury or damage incurred to any person or object related to the OIL/LIQUID EXTRACTOR.

### ANSWERS TO YOUR QUESTIONS

Should you want to order another OIL/LIQUID EXTRACTOR, or for a complete selection of quality GRIOT'S GARAGE products, please write, use the internet or call us toll-free and ask for item 10122.

*Have fun in your garage!*

GRIOT'S GARAGE, INC.  
3333 SOUTH 38<sup>TH</sup> STREET  
TACOMA, WA 98409  
**800-345-5789**  
**www.griotsgarage.com**

