



LIVE TO PLAY LIVE®




JIMDUNLOP.COM



92503017849REVA

PHOTO BY: CHUCK BOYD / © AUTHENTIC HENDRIX, LLC



Band of Gypsys™ Fuzz Face® Distortion

JHF3 BAND OF GYPSYS™ FUZZ FACE® DISTORTION

DESCRIPTION

- The biting, aggressive fuzz tone used by Jimi Hendrix for the Band of Gypsys show and other iconic performances
- True bypass

DIRECTIONS


- Run a cable from your guitar to the JHF3's INPUT jack and another cable from the JHF3's OUTPUT jack to your amplifier.
- Start with both controls at 12 o'clock.
- Turn the effect on by depressing the footswitch.
- Rotate the VOLUME knob clockwise to increase overall effect volume or counterclockwise to decrease it.
- Rotate the FUZZ knob clockwise to increase amount of fuzz or counterclockwise to decrease it.

POWER

The JHF3 is powered by one 9-volt battery (remove bottom plate to install).

CONTROLS

- 1** VOLUME knob controls overall effect volume
- 2** FUZZ knob controls amount of fuzz
- 3** FOOTSWITCH toggles on/ bypass



SPECIFICATIONS

Input Impedance	320 k Ω
Output Impedance	
Max Volume	11 k Ω
Mid Volume	64 k Ω
Max Output	+9 dBV
Max Gain	60 dB
Noise Floor*	-72 dBV
Effect Switching	THWBY
Current Draw	3.8 mA
Power Supply	9V Battery

*Measurements made at 1 kHz, all controls max.
A-weighted.



DUNLOP MANUFACTURING, INC.
P.O. BOX 846 BENICIA, CA 94510 U.S.A.
TEL: 1-707-745-2722 FAX: 1-707-745-2658