


# FLOOD PUMP

## Parts for Model PF75



# FLOOD PUMP

## Parts for Model PF75

ref#	order	description
1		Recovery Tank
2		Screw
3		Latch
4		Vac Inlet Barb
5		Adapter, PVC
6		Elbow, PVC
6A		Adapter, PVC
7		Pipe, PVC
8	<b>FP2</b>	Vacuum Inlet Filter
9		Lid
10	<b>FP4</b>	Lid and Bracket
11		Screw
13		Lock nut
14		Cord retainer, water tight
15		Float Switch
16		Elbow, 90 degree, PVC
18		Pipe, PVC
19		Adapter, Special
20		Drain Gate
20A		O-ring, large
21		Nut, Cast
21A		O-ring, small
22		Switch Plate, Guzler
22A	<b>FP1</b>	Switch, SPST with light
23		Screw
24		Gasket
25		Washer
26		Locknut
27	<b>1940</b>	Vacuum Motor
27A		Gasket, Vacuum Motor
28		Nut, Finish
29		Washer
30		Bolt
31		Hose Clamp (size 28)
32		Rubber Hose
32A		Rubber Hose
32B		Rubber Hose
33		Manifold, Vacuum

ref#	order	description
34		Hose, Polywire
3M		Hose Clamp
35		Hose Barb
36		Cord Retainer
37		Cap with Chain
37A		Brass Adapter
38		Reducer, PVC
39		T, Brass
39A		Washer, Flat, S/S
40		Base, Guzzler
41		Axle
42		Wheel
43		Axle Cap
44		Bolt
45		Axle Bracket
46		Locknut
47		Label
48		Louver
49		Exhaust Flange
50		Screw
51		Nut
52		Castor, Swivel
53		Latch Strike
54		Handle, Chrome
55		Screw
56	<b>FJ4125</b>	Pump, Diaphragm, Sump
57		Hose Barb
58		Screw
59		Washer, Flat
60		Locknut
61		Bracket, Pump Mounting
62		Hose, Polywire
63		Hose Clamp
64	<b>FP5</b>	Filter, Pump Inline
65		Elbow, 45 degree
65A		Hose Barb
66	<b>FP3</b>	Pump Filter, S/S