

Powr-Flite®

COMMERCIAL FLOOR CARE EQUIPMENT

Parts Manual



Dual Suction System Pro-Lite Model PF62EC

1-800-880-2913

POWR-FLITE LIMITED WARRANTY

Powr-Flite will repair or exchange parts for your vacuum in the event of a manufacturing defect as follows:

PARTS: New or comparable rebuilt parts, for one year after original purchase.

LABOR: Carry-in service can be obtained during the warranty period by taking your vacuum to an Authorized Powr-Flite Warranty Service Center.


IMPORTANT WARRANTY CONDITIONS: A purchase receipt or other proof of date of original consumer purchase also will be required before warranty service is rendered.

This warranty covers normal use and does not cover damage which occurs in shipment or failure resulting from alteration, accident, misuse, abuse, neglect, or improper maintenance.

STATEMENT: This warranty is not transferable and extends only to the original purchaser when a new Powr-Flite vacuum is purchased from an Authorized Powr-Flite Dealer. This warranty gives you specific legal rights, and you may have other rights that vary from state to state.

A Tacony Company, Fort Worth, Texas 76140-1710, Call Toll-Free (800) 880-2913

PARTS



ref#	part #	description
1	C431-4400	Handle Assembly
2	B431-4814	Upper Cord Hook
3	A428-2014	Main Switch Handle
4	B431-4914	Cord Hook Commercial
5	B431-4700	Handle Tube Rectangular
6	A090-0200	Screw
7	A090-0100	Cable Clamp
8	D431-4300	Upper Duct Diverter & Bag Mount Assembly
9	B431-4214	Rubber Collar
10	B211-4414	Bag Mount Foam Gasket
11	D431-0600	Zippered Cloth Bag Assembly
12	B431-4000	Duct Tube
13	B014-0814	Belt
14	B016-1400	Upright Stop w/Spring Clips
15	B017-3639	Nozzle Cover
16	B206-7900	Nozzle Label
17	D017-3600	Nozzle Cover Assembly
18	B029-0414	Furniture Guard
19	B012-3000	Agitator Assembly
20	B015-2414	Squeegee
21	B010-1414	Small Wheel

ref#	part #	description
22	B010-0900	Small Axle
23	B016-1314	Basetray
24	B014-0000	Belt Guard Hair Cutter
25	B016-0600	Left Pivot
26	B016-0400	Right Pivot
27	B018-0239	Lens
28	B051-0639	Lense Holder Cover
29	B051-0514	Motor Cover
30	D113-3200	Motor Assembly
31	D051-0000	Motor Housing Assembly
32	D051-0400	Duct Cover Assembly
33	B431-4114	Lower Cord Clip/Yoke Support
34	A028-0214	Male Plug
35	B051-0239	Post Filter
36	B051-0114	Post Filter Cover
37	A434-0831	Cord Set
38	A732-8314	Screw
39	A732-8414	Screw
40	A090-0300	Screw
41	A090-0400	Screw
42	A090-0500	Nylon Insert